



## Portable TSS Meter

### PSS-200

Using the battery to do power, portable design, suitable for field use stability, high precision data can be saved and query.

#### Technical Indexes

1. Measuring range: 5-1000mg/L
2. Basic error:  $\leq \pm 2\%$ (F.S)
3. Re-peatability:  $\leq \pm 2\%$ (F.S)
4. Minimum resolution: 0.01
5. Power: rechargeable lithium battery
6. Dimension: 80mm × 230mm × 55mm



#### Feature:

1. High performance ultra low power 16 bit microcontroller, the instrument standby time of up to 6 months or more.
2. With imported high performance, long life, high brightness light source, with high stability optical system, good repeatability, high precision.
3. Instrument is convenient, compact and convenient to carry on the spot inspection.
4. Can save the standard curve 10 and 199 values, with USB port, can be connected to the computer.
5. Cold light source, narrow band interference optical system, optical stability is good.
6. Data power protection function.
7. The main engine casing is molded ABS material, IP65 design, anti-corrosion, waterproof and dust proof performance is good.

#### Configuration list:

One set host 1, two pieces cuvette (5cm), one piece hood, a USB cable, a data acquisition CD, a charging power, a carrying case, a user manual, product certificate and 1 copy warranty card.